


EVACUATION DIAGRAM

EVACUATION ASSEMBLY POINTS



Fire Hose Reel



Manual Call Panel



Fire Hydrant



FIP Fire Indicator Panel

NEW AMS I
NTB-00498