

# Small Tutorial Room

## Overview

This guide provides basic instructions for the audio visual system. The system features a short-throw, interactive projector and whiteboard. The user can hold presentations from a laptop computer.

## Presentation Procedure

Press the **POWER** button to turn the projector on and off.  
Press the **AV MUTE** button to blank the display while the projector is on.


Press the **HDMI** button to display a connected laptop.  
Press the **WIRELESS** button to display the Wireless Presenter.  
Press the **AUDIO MUTE** button to mute the audio.  
Press the **VOL UP** button to increase the volume level.  
Press the **VOL DOWN** button to decrease the volume level.



## Connecting a Laptop/Document Camera

Connect a laptop or document camera to the 'Laptop' input located underneath the whiteboard using a HDMI cable.

Turn on the **Laptop** or **Document Camera**.

Configure the laptop to direct the video image to an external display. E.g. By selecting Function (Fn) + F3 or F5 or  + P on the laptop.  
Consult the laptop's help files for more information.

Use the document camera controls to operate the document camera.

## Connecting to the Wireless Presenter

See Instructions sheet:- **Wireless Presenter**

## Shutdown

**To ensure longevity of the audio visual equipment please double check the system is turned off prior to leaving the room (POWER indicator lights are blue).**

To ensure the equipment is ready for use by the next lecturer/presenter:

Press **Power** button to turn off the system, ensuring the **Power** button is **blue**.

**For assistance, please contact ITMS Technical Support  
Phone: 8946 6291 or Ext: 6291**