


Blue 2.2.25 TV Trolley Controls

Overview

This quick reference guide provides basic operating instructions for the TV Trolleys. The system features 55" LCD screen. The user can hold presentations from a connected laptop computer.

The system is controlled with the AMX 8-button panel.



Presentation

Procedure

Laptop Presentation

1. Press the **SYSTEM ON** button
2. Connect a laptop to the input using an HDMI cable and turn on the laptop.
3. Configure the laptop to direct the video image to an **external video display**.
Switching to an external display is usually done using one of the Function keys (E.g. Function + F3 or F5). Consult the laptop's help files for more information.
4. Use the **MIC VOL** buttons or the **VOLUME** knob to adjust the microphone volume level.
5. Shutdown the laptop and unplug the HDMI cable
6. Press the **SYSTEM OFF** button to turn off the system.

**For assistance, please contact Teaching Space Support, ITMS
8946 6291**